

Installation Process of Single Head Printer



Must read & Watch

Step By Step Process

Before Installation



Pre-Installation Instructions for DTF Printer

1. Prepare the Workspace

- Choose a clean, dust-free, and well-ventilated area.
- Maintain a room temperature of 20–28°C and humidity of 40–60% for stable printing.
- Ensure the table or stand is strong and level to support the printer weight.

2. Electrical Requirements

- Provide a dedicated power outlet with proper grounding earthing.
- Use a voltage stabilizer or UPS to protect the printer from power fluctuations.
- Avoid using extension boards with low-quality wiring.

3. Unboxing & Inspection

- Carefully open the package and check all items: printer, cables, ink bottles, powder, software dongle, and accessories.
- Inspect the printer for any physical damage during shipping.
- If any part is missing or damaged, do not continue installation—report immediately.

4. Positioning the Printer

- Leave enough space around the printer:
 - Front/Back: Minimum 1 ft
 - Sides: Minimum 6 inches
- Ensure the printer is placed on a stable, vibration-free surface.

5. Prepare the Inks

- Shake the CMYK + White ink bottles gently for 1–2 minutes before use.
- Make sure inks are fresh and not expired.

6. Software & Laptop Readiness

- Install the required software: Maintop / Acrorip / any provided RIP software.
- Disable antivirus temporarily if it blocks installation.
- Keep USB drivers and software dongle ready.

7. Ventilation & Fume Management

- If using a curing oven or shaker, ensure the room has proper exhaust.
- Keep fire-safety items nearby (basic precaution).

8. Clean the Printer Surface regularly

- Wipe the printer body, ink paths, and tray area with a microfiber cloth to remove dust.

9. Do Not Add Inks Yet

- Only fill the inks during installation.
- Wrong filling can damage the printhead.

10. Follow the installation video step by step for proper installation.

I understood I have to read and follow all instructions. Also I am declaring that if any mistake while installation then I will be responsible for that.

Customer Sign

Step 1

STEP BY STEP

INSTALLATION SINGLE HEAD PRINTER



Shaker Installation - Watch video then install shaker machine.

PART 1



WATCH NOW

Follow All Instructions Carefully. Don't Do anything different activity which not in video. If not understand then contact to engineer.

Step 2

Printer Installation - Watch video then install printer.

DAILY MAINTENANCE



WATCH NOW

QUARTERLY MAINTENANCE



WATCH NOW

PART 2



WATCH NOW

www.fedarindia.com